

Technical Data Sheet Wood 707 Exterior Sealer

1. Product and Storage Information

Product Description: A UV Curable Clear Exterior Sealer that is applied by spray, hand, roll, or brush. For use as a general purpose sanding sealer for new wood to create hardening, protection, sealing, and anchorage to achieve superior holdout for top coats. Better weathering performance. For Interior and Exterior wood products and furniture.

- High build.
- Easy sand, flow and level.
- Good production use.
- Excellent intercoat adhesion with optional sanding.
- Excellent wetting.
- Optically clear.
- Tintable.
- Better weathering performance.
- Used for wood hardening and protection.

Suitable Surfaces:

All Production Wood Products	Epoxy Primer
2K Surfacer / Undercoater	Base Coat
Tintable Sealer	Fully Cured Stains / Dyes

Storage: The product should be stored within the temperature range of 50°F to 90°F and in the original container. Do not return unused material into the original bottle.

Technical Data Sheet Wood 707 Exterior Sealer

2. Application



Use suitable respiratory and PPE equipment

See Section 6 (Liability/Hazard Info) for more details




Preparation Process: Use 91-99% isopropyl alcohol (IPA) to prep before application of the coating.

Prepare the wood surface to be coated by removing any dirt, debris, or contamination materials. Sand with 180-320 grit paper. Remove sanding dust.

Application Process: Shake or Stir well before use. Apply in a well-ventilated area, use appropriate PPE and a respirator (full / half mask) for spray coating (refer to SDS). Product can be applied outdoors in a well shaded environment. Care should be taken to prevent as much UVA exposure (natural sunlight) as possible. Brush, roll, or spray onto the substrate. Product can be applied at temperature ranges of between 60°F and 112°F as well as humidity up to 97%. Product temperature should be at minimum 72°F. Depending on spray equipment, product may need to be reduced no more than 20% to spray viscosity with 91-99% isopropyl alcohol, Substrate temperature should be at minimum 60°F. Any spray equipment may be used. The recommended tip size is 1.0 - 1.3 mm. Follow standard shop practice when spraying. The remaining unused polymer should be stored in an opaque container and may be reused as long as the viscosity has not increased. Unused polymer should not be returned to the original container. The spray equipment can be cleaned with isopropyl alcohol or acetone.

WARNING: material will start curing immediately when applied in direct or indirect sunlight.

Technical Data Sheet Wood 707 Exterior Sealer



Build Coats:

1. Apply 1 to 3 mils per application.

*Note: For vertical applications recommended coverage 1-1.5 mil.

*Film weight can be measured using a wet mil gauge.

2. Allow flow out to desired profile.

3. Cure for 2-4 min with UVA curing light or direct indirect/sunlight. Do not interrupt the cure cycle until tack-free.

4. Allow a 5 minute post cure before the next coat.

For additional coats, to achieve grain fill, sand with 220 grit, or finer, paper between coats. Use shop air and prep with IPA.

*For optimal outdoor performance, recommended dry film build is 3 mils above the surface of wood.

Repeat steps 1-4 for additional coats. Maxim build should be 4 mils above grain fill.


NOTE: Not recommended to exceed 4 mils above existing surface, pre-existing finish, or grain filled wood. Sealer is designed to be very rigid to improve holdout for top coats and is not designed to be polished.

Spray Gun Set-Up / Application Pressure:

RP - Gravity Feed	1.0 - 1.3 mm	15-35 psi
HVLP - Gravity Feed	1.0 - 1.3 mm	Max 20 psi (cap)

3. UV Through Cure Verification

Use this procedure to verify your UVA curing light is adequate to thoroughly cure the product. The UVA range to be used is between 365 - 405 nm.



1. Use a test article and apply a 3 mil coat.

2. Cure with UV light for 2 minutes.

3. Let rest for 10 minutes.

4. Check for a tack free surface. If it's not tack free then it has insufficiently cured*.

Technical Data Sheet Wood 707 Exterior Sealer

5. Take 220 grit sandpaper and sand completely through looking for dry powder all the way through. If you encounter gummy material or clogged sandpaper then it has insufficiently cured*.

***An insufficient cure indicates that the UVA light is unable to cure the product. (This could be due to the distance or total output power of the light). An insufficient amount of product down per application could result in an undercured coating.**

*Possible Reasons for Insufficient Cure:				
	Tacky Surface	Wet Surface	Wrinkled Surface	Bubbles present
Excessive film build	-	☑	☑	-
Insufficient film build	☑	-	-	-
Surface was not fully sealed	☑	☑	-	-
Insufficient curing light	☑	☑	-	-
Curing light is too intense	-	-	☑	☑
Curing light is too far away from the substrate	☑	☑	-	-
Curing light is too close to the substrate	-	-	☑	☑
Substrate was not fully dry	☑	☑	-	-
<i>*an insufficient cure is not limited to the items in this table</i>				

4. Cleaning Process

Use isopropyl alcohol and/or acetone to clean tools and equipment. Cure excess or unwanted material on surfaces or filters with UV light.

Technical Data Sheet Wood 707 Exterior Sealer

5. Material Details

Solid Content	100%
Volatile Organic Content	0%
Coverage @ 1 mil	1608 sq. ft./gal

6. Liability/Hazard Info

See SDS for complete information.

Although the product is VOC free it should be used in a well-ventilated area.

If skin contact occurs immediately wash with soap and water.

Harmful if swallowed.

Causes skin and eye irritation and may cause an allergic skin reaction.

WARNING: Exposing open containers or barrels of product to direct or indirect sunlight will result in a run away exothermic reaction. Product is unstable until properly cured.

Standard Disclaimer: EXCEPT AS SPECIFIED ABOVE OR PROHIBITED BY APPLICABLE LAW. ALL EXPRESS OR IMPLIED CONDITIONS AND WARRANTIES, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ACCURACY OF ANY INFORMATIONAL CONTENT, ARE HERE BY EXCLUDED AND DISCLAIMED BY CLEAN ARMOR TECHNOLOGY, LLC; AND IN NO EVENT WILL CLEAN ARMOR TECHNOLOGY, LLC BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWSOEVER ARISING AND REGARDLESS OF THE THEORY OF LIABILITY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. PRODUCTS, PRICES, AVAILABILITY, SPECIFICATIONS, AND OFFERS ARE SUBJECT TO CHANGE OR CANCELLATION AT ANY TIME WITHOUT NOTICE.

Personal Protective Equipment: Eye/face protection: Face shield and safety glasses Use equipment for eye protection tested and approved under appropriate government standards such as NIOSH (US) or EN 166(EU).

Technical Data Sheet Wood 707 Exterior Sealer

Skin protection: Handle with gloves. Gloves must be inspected prior to use. Use proper glove removal technique (without touching gloves outer surface) to avoid skin contact with this product. Dispose of contaminated gloves after use in accordance with applicable laws and good laboratory practices. Wash and dry hands.

Body Protection: Use a full paint suit with hood, The type of protective equipment must be selected according to the concentration and amount of the dangerous substance at the specific workplace.

Respiratory protection: Where risk assessment shows air-purifying respirators are appropriate, use a full-face respirator with multi-purpose combination (US) or type ABEK (EN 14387) respirator cartridges as a backup to engineering controls. If the respirator is the sole means of protection, use a full-face supplied air respirator. Use respirators and components tested and approved under appropriate government standards such as NIOSH (US) or CEN (EU).

Control of environmental exposure: Do not let product enter drains.