

## Technical Data Sheet Wood 720 Undercoater - White

### 1. Product and Storage Information

**Product Description:** A UV Curable White Undercoater that is applied by spray, roll, or brush. For use as a general purpose sealer or finish for new wood. Can be applied over new or pre-finished wood products. For Interior and Exterior wood products and furniture.

Excellent intercoat adhesion without sanding. Self sealing system. Good wetting. High build Interior and Exterior use. Good production use.

**Storage:** The product should be stored within the temperature range of 50°F to 90°F and in the original container. Do not return unused material into the original bottle. Pigmented products naturally settle over time. The product quality/shelf life can be maximized by agitating/stirring once every 7 to 10 days, as indicated on the product labels.

### 2. Application



**Use suitable respiratory and PPE equipment**

See Section 6 (Liability/Hazard Info) for more details




**Preparation Process:** Use 91-99% isopropyl alcohol (IPA) to prep before application of the coating.

**Prepare the wood surface to be coated by removing any dirt, debris, or contamination materials. Sand with 180-320 grit paper. Remove sanding dust.**

## Technical Data Sheet Wood 720 Undercoater - White

**Application Process: Shake or Stir well before use.** Apply in a well-ventilated area, use appropriate PPE and a respirator (full / half mask) for spray coating (refer to SDS). Brush, roll, or spray onto the substrate. Product can be applied at temperature ranges of between 60°F and 112°F as well as humidity up to 97%. Product temperature should be at minimum 72°F. Depending on spray equipment, product may need to be reduced no more than 20% to spray viscosity with 91-99% isopropyl alcohol. Substrate temperature should be at minimum 60°F. Any spray equipment may be used. The recommended tip size is 1.0 - 1.3 mm. Follow standard shop practice when spraying. The remaining unused polymer should be stored in an opaque container and may be reused as long as the viscosity has not increased. Unused polymer should not be returned to the original container. The spray equipment can be cleaned with isopropyl alcohol or acetone.

**WARNING: material will start curing immediately when applied in direct or indirect sunlight. Do not apply product with more than 3 mils per coat. Apply thin layers for best results.**



### Build Coats:

\*Surface should be fully sealed before applying the top coat.

1. Apply 1 to 3 mils per application.

\*Note: For vertical applications recommended coverage 1-1.5 mil.

\*Film weight can be measured using a wet mil gauge.

2. Allow flow out to desired profile.

3. Cure for 2-4 min with UVA curing light or direct sunlight.

4. Allow a 5 minute post cure before the next coat.

For additional coats, for best adhesion, thoroughly degloss with 320-800 grit paper or pad and remove sanding dust or prep with IPA to recoat. Can optionally be applied without sanding between coats to achieve good adhesion. Use additional coats to achieve desired coverage.

**Repeat steps 1-4 for additional coats.**

**NOTE: Not recommended to exceed 4 mils above existing surface, pre-existing finish, or grain filled wood. Sealer is designed to be very rigid to improve holdout for top coats and is not designed to be polished.**


## Technical Data Sheet Wood 720 Undercoater - White

### Spray Gun Set-Up / Application Pressure:

|                     |              |                  |
|---------------------|--------------|------------------|
| RP - Gravity Feed   | 1.0 - 1.3 mm | 15-35 psi        |
| HVLP - Gravity Feed | 1.0 - 1.3 mm | Max 20 psi (cap) |

### 3. UV Through Cure Verification

Use this procedure to verify your UVA curing light is adequate to thoroughly cure the product. The UVA range to be used is between 365 - 405 nm.



1. Use a test article and apply a 3 mil coat.
2. Cure with UV light for 2 minutes.
3. Let rest for 10 minutes.
4. Check for a tack free surface. If it's not tack free then it has insufficiently cured\*.
5. Take 220 grit sandpaper and sand completely through looking for dry powder all the way through. If you encounter gummy material or clogged sandpaper then it has insufficiently cured\*.

**\*An insufficient cure indicates that the UVA light is unable to cure the product. (This could be due to the distance or total output power of the light). An insufficient amount of product down per application could result in an undercured coating.**

## Technical Data Sheet Wood 720 Undercoater - White

| <b>*Possible Reasons for Insufficient Cure:</b>                        |                                     |                                     |                                     |                                     |
|------------------------------------------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
|                                                                        | Tacky Surface                       | Wet Surface                         | Wrinkled Surface                    | Bubbles present                     |
| Excessive film build                                                   | -                                   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | -                                   |
| Insufficient film build                                                | <input checked="" type="checkbox"/> | -                                   | -                                   | -                                   |
| Surface was not fully sealed                                           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | -                                   | -                                   |
| Insufficient curing light                                              | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | -                                   | -                                   |
| Curing light is too intense                                            | -                                   | -                                   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Curing light is too far away from the substrate                        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | -                                   | -                                   |
| Curing light is too close to the substrate                             | -                                   | -                                   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Substrate was not fully dry                                            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | -                                   | -                                   |
| <i>*an insufficient cure is not limited to the items in this table</i> |                                     |                                     |                                     |                                     |

### 4. Cleaning Process

Use isopropyl alcohol and/or acetone to clean tools and equipment. Cure excess or unwanted material on surfaces or filters with UV light.

### 5. Material Details

|                                 |                         |
|---------------------------------|-------------------------|
| <b>Solid Content</b>            | <b>100%</b>             |
| <b>Volatile Organic Content</b> | <b>0%</b>               |
| <b>Coverage @ 1 mil</b>         | <b>1608 sq. ft./gal</b> |

## Technical Data Sheet Wood 720 Undercoater - White

### 6. Liability/Hazard Info

See SDS for complete information.

Although the product is VOC free it should be used in a well-ventilated area.

If skin contact occurs immediately wash with soap and water.

Harmful if swallowed.

Causes skin and eye irritation and may cause an allergic skin reaction.

**WARNING:** Exposing open containers or barrels of product to direct or indirect sunlight will result in a run away exothermic reaction. Product is unstable until properly cured.

**Standard Disclaimer:** EXCEPT AS SPECIFIED ABOVE OR PROHIBITED BY APPLICABLE LAW. ALL EXPRESS OR IMPLIED CONDITIONS AND WARRANTIES, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ACCURACY OF ANY INFORMATIONAL CONTENT, ARE HERE BY EXCLUDED AND DISCLAIMED BY CLEAN ARMOR TECHNOLOGY, LLC; AND IN NO EVENT WILL CLEAN ARMOR TECHNOLOGY, LLC BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWSOEVER ARISING AND REGARDLESS OF THE THEORY OF LIABILITY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. PRODUCTS, PRICES, AVAILABILITY, SPECIFICATIONS, AND OFFERS ARE SUBJECT TO CHANGE OR CANCELLATION AT ANY TIME WITHOUT NOTICE.

**Personal Protective Equipment:** Eye/face protection: Face shield and safety glasses Use equipment for eye protection tested and approved under appropriate government standards such as NIOSH (US) or EN 166(EU).

**Skin protection:** Handle with gloves. Gloves must be inspected prior to use. Use proper glove removal technique (without touching gloves outer surface) to avoid skin contact with this product. Dispose of contaminated gloves after use in accordance with applicable laws and good laboratory practices. Wash and dry hands.

**Body Protection:** Use a full paint suit with hood, The type of protective equipment must be selected according to the concentration and amount of the dangerous substance at the specific workplace.

**Respiratory protection:** Where risk assessment shows air-purifying respirators are appropriate, use a full-face respirator with multi-purpose combination (US) or type ABEK (EN 14387) respirator cartridges as a

## **Technical Data Sheet Wood 720 Undercoater - White**

---

**backup to engineering controls. If the respirator is the sole means of protection, use a full-face supplied air respirator. Use respirators and components tested and approved under appropriate government standards such as NIOSH (US) or CEN (EU).**

**Control of environmental exposure: Do not let product enter drains.**